


Bruksanvisning

Infravärmare

Art. No. 3012.200

Model	3012.200
Voltage(V) - Volt (v)	220-240VAC
Wattage(W) - Watt (W)	2000W
Hertz(Hz) - Hertz (Hz)	50/60 Hz
Dimensions (mm) - Mått (mm)	800x200x200
Weight(KG) - Vikt (KG)	3.8
Ingress protection - Kapslingsklass	IP44



Varning

- Montera aldrig infravärmaren omedelbart under ett fast vägguttag. Infravärmaren ska monteras så att den i strålningsriktningen sitter minst 1 meter från brännbara föremål t.ex. gardiner.
- Apparaten får ej användas av barn 0-8 år eller av personer med nedsatt funktionsförmåga. Barn från 8 år samt personer med nedsatt funktionsförmåga får använda apparaten om man fått instruktioner av faror etc.
- Vissa delar av värmaren kan bli väldigt heta och orsaka brännskador. Särskild uppmärksamhet måste vidtas om barn eller personer med nedsatt funktionsförmåga är närvarande.
- Vid upppackning av produkt, kontrollera att varan är i gott skick innan användning.
- Kontrollera hushållspänningen för att säkerställa att den överensstämmer med produktens nominella specifikation.
- Stäng av strömmen innan du drar ut strömsladden. Se till att dina händer är torra för att förhindra elektriska stötar när du sätter på produkten.
- Använd inte med förlängningssladd eller grenuttag.
- Placera inte produkten i närheten av ett badkar, tvättställ, simbassäng, duschtrymmen eller annan vattenkälla.
- Koppla alltid ur produkten när den inte används.
- Sätt inte fingrar eller främmande föremål i grillen när den är igång.
- Denna produkt är inte avsedd att användas i badrum, tvättstugor eller liknande inomhusplatser.
- Vi kan inte acceptera något ansvar för skada som orsakats av bristande efterlevnad av dessa instruktioner eller annan felaktig användning eller felaktig hantering.

Rengöring

Vid eventuell rengöring ska följande försiktighetsåtgärder vidtas.

- Kontrollera att strömkretsen är bruten.
- Kontrollera att infravärmaren ej är varm.
- Använd endast en lätt fuktad trasa eller duk och torka av utsidan av infravärmaren.
- Använd ej vassa föremål vid rengöring.
- Vänta tills infravärmaren är torr innan användning.

OBS

- Infravärmaren får ej övertäckas, det medför brandfara.
- Ej för industriellt bruk.

Återvinning

Denna elektriska produkt får inte kastas med hushållsavfall. Återvinn på en återvinningsanläggning. Kontakta din lokala myndighet för rådgivning.

Warning

- Never place the heater immediately under an electrical socket. The heater shall be mounted so that the front of the heater is at least 1 meter away from flammable objects such as, curtains.
- The heater is not to be used by children between the age of 0 - 8 or by persons with reduced physical, sensory or mental capabilities, unless they are under supervision or have been given instructions concerning the proper use of the heater by a person responsible for their safety.
- Parts of the heater may become extremely hot and cause severe burns. Therefore, special supervision should be practised around children or vulnerable people.
- When unpacking the product, ensure it is in good condition before using.
- Check the household voltage to ensure it matches the heater's rated specification.
- Ensure to turn off the power before unplugging the product. Be sure your hands are dry to prevent electric shock before turning the heater on.
- Do not use with an extension cord or relocatable power tap.
- Do not use the heater near or in the vicinity of a bath, sink, swimming pool, shower, or other source of liquid.
- Always unplug the heater when not in use.
- Do not put fingers or foreign objects into the grill while in use.
- This heater is not intended to be used in bathrooms, laundry rooms, or similar indoor rooms.
- No liability can be accepted for any damages cause by non-compliance with these interactions or any other improper use or mishandling.

Cleaning

Should you choose to clean the heater, the following precautions must be followed.

- Make sure to unplug the power cord.
- Ensure that the heater is not hot and that it has been given time to cool down.
- Use a soft, damp cloth to clean the outside of the heater.
- Do not use sharp instruments to clean.
- Make sure the heater is dry before use.

Note

- Do not cover the heater due to risk of fire.
- Not for commercial use.

Recycling

This electrical product should not be disposed off with household waste. Please recycle where facilities exist. Check with your local authority for recycling advice.

